



**Can you  
carry jumbo  
loads ?**

## The Domino (4) XL

...more payload, more cube and tough !



### SLING-LIFT POINTS

How do you lift a flatrack out of a cell guide without a spreader? Use the in-board sling lift points without breaking the flatrack.

### BEAT OBSOLESCENCE

Upgrade your 8ft6in DOMINO at any time to 9ft6in or 10ft6in. You can then flush fold the extended posts without removing them.

### OVER-HEIGHT PROFIT


Tall cargo is not a problem with 1ft or 2ft Post Extenders which provide full strength racking and stacking...and pay off in one trip.

### NEW XL HINGE STRENGTH

100T stacking, hook lifting point, 34T lift and twice normal racking make this tough to beat, giving you less damage and longer life.

### 60T MGW OPTION

Increasing use of flatracks as 'tween decks, make this a definite option, yet tare weight and cost still remain low for normal cargo.



**DOMINO Flatracks Ltd**  
Wootton Paddox  
Leek Wootton  
Warwickshire CV35 7QX UK

Tel: +44 (0) 1926 863 140  
Fax: +44 (0) 1926 863 141  
E-mail: [info@flatrackcontainers.com](mailto:info@flatrackcontainers.com)  
Web: [www.flatrackcontainers.com](http://www.flatrackcontainers.com)

**[www.flatrackcontainers.com](http://www.flatrackcontainers.com)**  
WORLD LEADERS IN INNOVATIVE DESIGN AND MANUFACTURE

